



Apply caulking between spacer plate and box as well as between the plate and back of cabinet. (Use water-tight fitting)



Note: Power and signal can run to Add-On first if desired. Make connections shown to left in Add-On Electrical Enclosure

POWER REQUIREMENTS	
Model	Current @120/240 V
5633	1.0/0.5A
PCD-08	0.056/0.028A
PCD-10	0.056/0.028A
PCD-16	0.056/0.028A
PCD-18	0.056/0.028A

Note:
1) Water tight fittings are required (supplied by others)
2) Conduit supplied by others

**Add-On
Power/Communication
Installation**

Drawn **DBB** Date **09/22/11**

NEVCO
Nevco, Inc.
Greenville, Illinois 62246

Drawing No. **275-0693**

Sheet of **1** **1**